

The Burnerworld Guide to... "Removing Aero Zytec Wheel Hubs"

1. Get yourself a couple of spanners and an allen key. This is how your Zytec mag should look before you start!
2. Unscrew the spacer nut on one side of the axle, until completely off.



3. Undo all four allen bolts as pictured.
4. The hub should be loose at this point.



5. Pull the axle through the one side, until completely removed.
6. Both sides of metal casing should be off by now, and you will be left with a hub free wheel, as pictured!



7. Now you are just about ready to bleach/dye your aero Zytec mags!

